

CREATIVE THINKING EXCEPTIONAL SOLUTIONS

Laboratory Assessment of Injectable Activated Carbon on Biological Reductive Dechlorination of Chlorinated Ethenes

Dimin Fan, PhD, Staci Capozzi, PhD, James Wang, PhD, PE,
Geosyntec Consultants


Larissa Smith, Sandra Dworatzek, **SiREM**

Birthe Kjellerup, PhD, Amir Riyahi, **University of Maryland, College Park**

Joe Pignatello, PhD, Zhengyang Wang, PhD, **Connecticut Agricultural
Experiment Station**



Motivation



Fundamental – Pore scale




Practical – Plume scale

- Characterization of injectable activated carbon
- Batch Microcosm biological dechlorination with CAC
- Flow-through columns: biological dechlorination with CAC

Characterization of Injectable AC

- AC acquisition:
 - F400: granular, powder, and colloidal AC
 - Commercial CAC: Polymer and polymer free
- Physical and chemical characterizations
 - CAC has slightly higher surface area and ultra-porosity
 - CAC is more hydrophilic due to surface oxidation during milling
- Sorption isotherm of TCE
 - Particle size effect is negligible
 - Polymer decreased sorption affinity and capacity

TCE Sorption Isotherm



Microcosm Biological Dechlorination Experiment


	Treatment/Control	Description	Number of Replicates	Sacrificial bottles
1	Anaerobic Sterile Control	Autoclaved and amended with mercuric chloride and sodium azide	2	3 x 2
2	Intrinsic Bio Control	KB-1 bioaugmented	2	3 x 2
3	2,000 mg CAC/kg sand Sorption Control	Amended with CAC	2	6 x 2
4	200 mg CAC/kg sand/ KB-1® Bioaugmented	Amended with a low dose of CAC and KB-1® bioaugmented	2	6 x 2
5	2,000 mg CAC/kg sand/ KB-1® Bioaugmented	Amended with a medium dose of CAC and KB-1® bioaugmented	2	6 x 2
6	4,000 mg/kg CAC /kg sand/ KB-1® Bioaugmented	Amended with a high dose of CAC and KB-1® bioaugmented	2	6 x 2
7	#6 + 5 g/L CaCl ₂	#6 + flocculant	2	6 x 2
Total Microcosms			14	72

Microcosms consist of 10 g sand + 30 mL of AGW sealed by mininert valves







Microcosm Construction and Incubation

Construction + Incubation




- Measure aqueous TCE 1-day after CAC addition
- KB-1 added first without lactate to assess if polymer serves as e donor
- Sampled aqueous VOCs and extracted solid VOCs

Sorption Slows Down Dechlorination – Availability Limit




Dechlorination Biomarker Abundance




Column Biological Dechlorination Experiment


- Treatment
 - KB-1 only
 - 200 mg/kg CAC with and w/o KB-1
 - 1,000 mg/kg CAC with and w/o KB-1
- Column conditions
 - Continuously feeding ~10 mg/L TCE in artificial GW
 - Continuously feeding lactate to bio columns
 - CAC only columns: no lactate but not sterilized
 - KB-1 inoculated within CAC barrier (Port B)
 - 13-week operation with adjusted conditions
 - Post column characterizations



Column Results – 1,000 mg/kg CAC




Column Results – 1,000 mg/kg CAC + KB-1




First six weeks:

- Early TCE to cDCE in Port A
- Lower flow rate after week 4 slightly enhanced VC production at week 6 due to longer residence time

Column Results – 1,000 mg/kg CAC + KB-1




Column Results – 1,000 mg/kg CAC + KB-1




Column Results – Effect of CAC Loading on Treatment

Week 11 – 1/3 PV per day


No CAC



200 mg/kg CAC



1,000 mg/kg CAC




- All columns showed near complete dechlorination in Port C and effluent.
- CAC columns had no detectable aqueous cDCE in within the CAC barrier (Port B).


Column Results – Effect of CAC Loading on Treatment

Week 13 – 1 PV/day (Stress Test)


No CAC



200 mg/kg CAC




1,000 mg/kg CAC



- Less dechlorination at high flow rate, but high CAC showed the lowest cDCE breakthrough.
- Significant solid cDCE mass associated with CAC.

Microbial Characterization – Dechlorinator, SRB, and Methanogens



Conclusions

- TCE sorption was similar for different AC sizes, but polymer decreased sorption.
- Microcosm dechlorination
 - CVOC bioavailability limited biodegradation
 - Solid extraction is needed to fully assess degradation
- Flowthrough columns:
 - Observed biodegradation with high CAC loading
 - Competition from sulfate reducers
 - Treatment performance depended on the mass flux and degradation rate
 - Sorption provided additional capacity to limit breakthrough of cDCE and VC



Next Step

- Microbial and microscopic characterization of solid phases
- Additional column test
 - Lower influent concentration,
 - Sulfate,
 - Electron donor level, and
 - Different types of AC
- Develop a conceptual model to describe the pore-scale process

Acknowledgements



ER21-1224 (<https://serdp-estcp.mil/projects/details/e57d3350-6250-4051-9eb8-aa54ceb2d1cb/er21-1224-project-overview>)

Dynamic Interactions between Sorption and Biodegradation: Implications for Long-Term Performance of Activated Carbon-Based Technology for In Situ Groundwater Remediation of Chlorinated Solvents

Geosyntec
consultants

engineers | scientists | innovators


**Technology
Advisory Council**




CREATIVE THINKING
EXCEPTIONAL SOLUTIONS

dfan@geosyntec.com
443-518-8775

Microbial Characterization – Spatial Distribution of Dechlorinators



Aqueous Phase Concentrations are Not Sufficient



Dynamics between Sorption and Biodegradation

