


Nanofiltration Followed By Electrical Discharge Plasma for Destruction of PFAS and Co-Contaminants in Groundwater: A Treatment Train Approach



2024 International Conference on Remediation of Chlorinated and Recalcitrant Compounds

3 June 2024



Stephen Richardson, PhD, PE
Poonam Kulkarni, PE
Whitney Bailey, PE
Chris Bellona, PhD
Nicole Masters
Selma Mededovic, PhD
Thomas Holsen, PhD
Ken Camarco
Will Knutson
Charles Schaefer, PhD




Technical Objectives

What's Needed?

- › Since PFAS plumes are generally dilute (often a few ppb), remediation of PFAS-impacted water best lends itself to a treatment train approach with integrated ***PFAS concentration and destructive steps***

Our Objective


- › Demonstrate and validate a field-scale integrated treatment approach:
 - 1 ***Nanofiltration*** to concentrate PFAS and co-contaminants
 - 2 ***Electrical Discharge Plasma*** to treat concentrate
 - 3 “Apple to Apples” Bench-scale comparison of ***Electrochemical Oxidation and Plasma***



Nanofiltration: *The Basics*




- › High-pressure separation process where solutes are retained by membranes and concentrated into a smaller volume of water (*retentate or concentrate*)
- › Majority of feed water exits system as treated *permeate (or filtrate)*
- › **% Recovery:** proportion of feed water recovered as permeate
- › **% Rejection:** proportion of solute (PFAS) retained by the membranes



Enhanced Contact Plasma: *The Basics*



- › Uses electricity to convert water into a mixture of highly reactive species (e.g., hydroxyl radicals, aqueous electrons)
- › Rapidly and non-selectively degrade recalcitrant organic contaminants (e.g., PFAS)
- › **Plasma Formation:** High voltage applied between suspended electrodes and submerged grounded electrodes
- › **PFAS Destruction:** Argon gas bubbles drive PFAS to the liquid surface for interaction with plasma



Field Demonstration:


Experimental Conditions

Nanofiltration


- › Membranes: NF90 and CR100
- › Recovery Setpoints: Low (80%), Medium (85%) and High (90%)

Enhanced Contact Plasma


- › Mode of Operation:
 - › Continuous Recycle (single reactor)
 - › Flow-through (three reactors)



Field Demonstration: *Site Characteristics*




Average Σ PFAS Conc = 10,450 ng/L




- › Most abundant PFAS: PFOS, 6:2 FTS, and PFHxS
- › Elevated alkalinity, calcium, and iron


Field Demonstration: *In Action!*




Field Demonstration: *Process Flow*





Field Demonstration: *Sample Locations*



Process Flow: *Pre-treatment*




Process Flow: *Nanofiltration*




- During filtration, concentrate recirculated internally, concentrate valve closed
- Once a recovery setpoint is reached, concentrate valve opens
- With concentrate valve open, plug-flow flush displaces concentrate in system
- Concentrate valve closes, new cycle starts


Process Flow: *Enhanced Contact Plasma*



Process Flow: *Polishing*




Results: *Treated Volumes*



- › 16,000 gallons of PFAS-impacted groundwater
- › Generated 13,500 gallons of treated permeate
- › Generated 2,500 gallons of PFAS-containing retentate
- › 1,800 gallons of retentate was treated using the enhanced contact plasma reactor
- › All generated water was polished using GAC prior to discharge

System Performance: **PFOA**


- › **Pre-Treatment:**
Minimal impact on concentrations
- › **Permeate:** Below detection limits
- › **Retentate:** ~10X concentration factor
- › **Plasma Treatment:**
 - › >90% reduction in concentrations
 - › Variable results



PL = Plasma; NF = Nanofiltration

System Performance: *PFOS*

- › **Pre-Treatment:**
Minimal to low impact on concentrations
- › **Permeate:** low concentrations
- › **Retentate:** ~10X concentration factor
- › **Plasma Treatment:**
 - › Variable results




PL = Plasma; NF = Nanofiltration

Nanofiltration Performance:


Net Driving Pressure



CR100 Membrane: High Recovery (90%)



NF90 Membrane: High Recovery (90%)



- › Consistent cycling indicates no fouling of membranes through experiments

Nanofiltration Performance:

NF90 Membrane, High Recovery (90%)




Retentate:

- › Achieved 7-13X concentration factors
- › Consistent with recovery set point

Permeate:

- › PFOS and PFHxS detected at low conc.
- › >90% removal for most compounds
- › % removal calcs affected by detection limits




Plasma Performance:

Flow-Through




NF90 Retentate (90% Recovery)

- › Strong removal of precursors and long-chains
- › >90% reduction of PFOA and PFOS
- › Production of PFBA and slow decline of PFPeA attributed to degradation of long-chain PFAS & unidentified precursors



System Performance: Overview



- **Nanofiltration:** Highest concentration factors observed for CR100 membrane at 90% recovery
- **Plasma:** Similar removal with retentate from each membrane

Key Points: *Overview*

Nanofiltration

- › ~13,500 gallons of treated permeate
 - › >5 – 10X concentration of source water
- › >99% PFAS separation for most PFAS
 - › PFOS detected in permeate
- › CR100 performed better than NF90
 - › Minimal permeability loss

Enhanced Contact Plasma

- › 1,800 gallons of treated retentate
- › Percent Removal:
 - › Precursors: 19-99% (median = 91%)
 - › $\geq$ C6 PFAAs: 53-97% (median = 93%)
 - › C5/C4 PFAAs: -125% - 97% (median = -6%)
- › Potential cross-contamination within the system



Acknowledgements



*GSI
Environmental*

**Stephen Richardson, Poonam Kulkarni, Alison
Denn, Katie Welch, Cassidy Powell, & Sage Clay**



*Colorado School
of Mines*

Christopher Bellona & Nicole Masters
Nanofiltration Design & Operation



*Clarkson
University*

Selma Mededovic & Tom Holsen
Plasma Reactor Testing & Analytical



*DMAX Plasma
Inc*

**Ken Camarco, Chase Nau-Hix, Will Knutson, Tom
Holsen, & Selma Mededovic**
Plasma Reactor Design & Operation



CDM Smith

Charles Schaefer & Dani Tran
Electrochemical Oxidation Testing

QUESTIONS?

